

Shoez'On Shoe Cover Dispenser


Thank you for purchasing the Shoez'On Shoe Cover dispenser

Please take a moment to read the notes shown on this publication and you will have years of safe use from your Shoez'On machine

Please check the parts included in your Machine and contact us should anything appear to be missing

Assembly and preparation for use is extremely simple.

Please note that first time users may appear confused and hesitant at first use, but the successful cover of one shoe will convert them into a lifetime user in minutes!!




Assembly & Operating Instructions

Assembly

1. Install the hand rail / support handle
(See Diagram 1)

The two pieces of tube supplied with your Shoez'On machine are designed to slot together. Included in the kit are two screws. Use the brass coloured machine thread screw to ensure that the tubes are secured together.

The silver or zinc plated self tapping screw is used to secure the support tube to the body of the Shoez'On once the hand Rail is inserted into its hole. (See Diagram 2)




2. The Top cover (white) of your Shoez'on is secured to the base using two cream coloured plastic nylon clips. Slide them towards the "off Mark" and the cover can now be detached from the base (See Diagram 3)
3. Note that the supplied roll of adhesive must be installed with the adhesive / sticky side facing upwards. Slip it over the Blue Roll holder and insert the holder into the base of the machine. (See Diagram 4)
4. Pull the start of the adhesive roll all the way towards the back of the machine and leave it lying on top of the cushion mat. (See Diagram 5)

5. Replace the white top cover of the Shoez'On machine and secure the cover with the two cream nylon clips whilst at the same time ensuring that the white plastic pegs engage into the holes on the top of the base. (See Diagram 6)

Operating Instructions

1. Stand behind your Shoez'on Machine and hold the knob of the handrail/support rail with your left hand
2. Place your right foot/shoe into the machine and press firmly down onto the cushion mat.
3. Whilst still balancing hold the handle with your left hand, withdraw your foot backwards dragging the tape that is now adhering to the sole of the shoe out and over the rear of the machine.



- As you press your foot down onto the ground at the rear of the machine the blade cover will drop in-front of your foot and the adhesive will be cut in-front of your shoe.
4. (It may require a little practice to perfect this action but usually after one or two attempts a user is well trained).
 5. Repeat the action for the left foot and your are off and going!!
 6. You can use the cut out slot at the base of the rear of the machine to smooth any extra adhesive tape over the toe cap of your shoe if necessary.
 7. Please note that the current batch of machines DO NOT include any form of cleaning brushes as shown on the included instruction manuals.

Warnings and maintenance

1. Always ensure that the tape is spread evenly across the full width and length of the cushion.
2. Avoid stepping on the serrated cutting blade.
3. As the mechanism of the machine involves the use of a serrated tape cutting blade, please Do Not allow children or the infirm to use this machine unsupervised.
4. The machine should not be immersed in water.
5. Exposure to very hot climate temperatures such as the rear window of a car in high heat could cause the product to warp and certainly will affect the adhesion and quality of the protective tape.
6. Always use the recommended and supplied Low tack adhesive with your Shoez'On machine. Use of any other tape may prove difficult to remove from shoe soles and may indeed damage shoes and floor coverings.
7. To ensure that the machine cuts the tape cleanly each time please remove any tape residue build up on the serrated edges.

SANZI IMPORTS LTD
Unit 5
93 Ellice Road
Glenfield
Auckland
New Zealand
Shoez-on@sanzi.co.nz